

INDEX FOR DPS24 Operator's Manual for OS v1.60

v1.0 8/16/2005

Created and maintained by Johnny Rock of

Jango Rhythm (www.jangorhythm.com)

Corrections/additions to: johnnyrocku@yahoo.com

!!! SOLO !!! 21
2-TRACK 5, 21
24-Track Xfer 205

A

Abort Record 40
ADAT & Digital Clock 206
ADAT I/O 4, 203
ADAT LRC Key Assignment 215
ADAT OUTPUT ASSIGN 109
ADJUST 78
AFL 101
AMOUNT 78
Analog input channels 4, 9
ASCII Keyboard Command Chart 215
Assign Keys 11
ATTACK 92, 93
ATTENUATION 88
AUDIO RECOVERY 185
AUDIO SETUP 177
AUTO 34
AUTOLOCATOR 42
AUTOMATED EVENT EDITOR 125
AUTOMATED SCENE RECALL 121
AUTOMATED SNAPSHOT RECALL 121
AUTOMATION 32, 49, 113
Automation Edit 56
AUX IN 6
AUX OUTPUT ASSIGN 109
Auxiliary Sends 4

B

Backing Up Projects 158
BIT DEPTH 168
BPM (DSP) 80

C

CANCEL 34
CD PLAYER 201
CD-Recorder 188
CD-RW/CD-R Drive 7
CHANNEL 87
Channel Dynamics 92
Channel Insert Sends>Returns 4
CHANNEL ON Screen 85
CHANNEL SOURCES 107
CHORUS 138
CLEAR AUTOMATION 120
CLEAR DYNAMIC AUTOMATION 120
COMBINED (FX) 137
COMP/EXPANDER 92
Compressor 92
Compressor/Expander, Multi-band 194
Compressor Preset Libraries 94
Contrast Control 23
COPY 57
COUNTER RESET 50
CREATING Projects 152
CURSOR 33
CUT 58

CYCLE 50

D

Data Entry with Q6 89
DELAY (FX) 134
Digital I/O 4
DIGITAL OUTPUT ASSIGN 109
DIGITAL SYNC 167
DISK 182
DISK-AT-ONCE (CD-ROM) 191
DISK COPY (Project) 157
DISK FORMAT 184
DISK RECORD GROUP ASSIGN 110
DISK RECORD SOURCES 108
DISTORTION (FX) 143
DOWNSAMPLING 190
DPS24 Block Diagrams 208
DPS24 Modes 49
DPS24 Specifications 216
DROPOUT MODE 114
Dropping out of record 40
DSIP 102
DSP 76
DYNAMICS (FX) 144
Dynamics Processor 92
Dynamics Snapshots 97

E

EDIT 32, 49, 52
Edit Play Keys 41
Editing Events 126
Editing FX 129
Effects (See FX)
ENHANCER (FX) 143
ENTER 34
ERASE 58
EQ (FX) 143
EQ Preset Libraries 94
EQ Snapshots 97
EVENT EDITOR 125
Expansion Slots 6
EXT SYNC 32, 202
EXT SYNC Offset 203

F

Fader Bank 18
Fader Flip 14
FADER MOTORS 114
Faders 18
FAST FORWARD 40
Features 1
FLANGER (FX) 139
FOOTSWITCH 5, 172
FORMAT DISK 182
FROM 41
Front Panel 7
FULL FORMAT 184
FX/AUX Screen 85
FX Edit 129
FX In CR Mix 151
FX In Foldback Mix 151
FX Factory Presets 131
FX Library 130
FX Mode 32, 49, 127
FX, Multiple 150
FX Recall 128, 131

FX, Recording 150
FX RTN GROUP ASSIGN 110
FX RTN SOURCES 108
FX SEND/RETURN LEVELS 150
FX Snapshots 148
FX Store 129
FX/AUX SENDS 90
FX/AUX SETUP 105

G

Gate 93
Gate Preset Libraries 94
GOTO 42, 44, 45
GRID 51
Ground terminal 6
Group Assignment 11
Groups 110

H

Headphone level 7
Headphone output 7
HI-Z input 7
HOLD 93
HYSTERESIS 93

I

IN/OUT keys 47
IN>OUT 41
Initial Scene 39
INP MON 34
INPUT CHANNEL GROUP ASSIGN 110
INPUT CHANNEL SOURCE 107
INPUT SOURCE 88
Inputs 4, 9
INPUTS/FX/GROUPS Screen 86
INSERT 59
ISOLATE 103

J

Jog/Shuttle Wheel 47

K

Keyboard Input 5

L

L/R Bus Assign 111
L/R Bus Assignment 11,12
LCD 23
LCD Layout 24
LEVEL 84
Linking Channels 100
LOAD Project 152
Locating to Timecode 46
Lock Lever (removed from manual)

M

Main Monitor Output 5
MAIN SCREEN 32, 49, 50
Master 20
Master Stereo Output 5
Mastering on DPS24 199
MBCX Presets, Loading/Saving 198

MEMORY 42, 43
METER 88, 89
Meter Bridge 26
METER VIEW 50
METRO 50
METRONOME 172
MIDI Implementation Chart 207
MIDI IN/OUT/THRU 5
Mix Scene 35
Mix Scene, Recalling 37
Mix Scene, Storing 36
MIXDOWN 189, 193
MIXER 32, 49, 84
Mixview 86
MMC ID 169
MMC SETUP 169
Modes 49
MONITOR LEVEL 21
Monitoring 21
MONO 22
MOVE 61
Multi-band Compressor/Expander 194
Multiple Effects 150
Multi-Purpose LightPipe 4

N

Naming items 30
NEAR/MAIN keys 22
NEARFIELD 5
NEW project 152
N.GATE 93
No. of Inserts 59
No of Pastes 60
Noise Gate 93
NORMALISE (DSP) 82

O

Offline DSP functions 76
Options Installation 212
OS Update 180, 213
OUT key 47
OUTPUT GAIN 92
OUTPUTS PATCH Screen 109

P

PAN (FX) 141
PAN Screen 84
PASTE 60
PATCH 107
PATCH GROUPS 110
PATCH L/R 111
PATCH OUTPUTS 109
PATCH PRESETS 112
PFL 101
Phantom Power 9
PHASE INVERT 88
PHASER (FX) 140
PITCH CORRECTOR (FX) 146
PITCH SHIFT (DSP) 79
PITCH SHIFT (FX) 142
PLAY 40
Play From 41, 172
Play IN>OUT 41
Play Over 41, 172
Play To 41, 172
POST-ROLL 33

Power 6
Powering up 48
PRE_ROLL 33
PREFS 168, 172
Presets, Copy/Backup/Restore 159
Presets, Libraries 94
Progress Display 31
PROJECT 33, 49, 152
Project Backup From External Disk 159
Project Disk Copy 158
Project Info Bar 24
Projects, Managing 156
Project, New 152
Project Overview 26
Project USB Copy 158
Project LOAD 152
Project Restore 160
PROJECT TOOLS 155, 156
Prompts 31

Q

Q-Channel 15
Q-Link 23, 27
Q-Strip Channel Encoders 13
Q-Strip Function keys 13, 17
QUICK FORMAT 184
Quick Locate Keys 45

R

RANGE 93
RATIO 92
REAR PANEL 4
Recall Locate Memory 42
Recall Scene 35, 37
Recalling FX 128, 131
RECORD 40
Record Abort 40
Record Drop Out 40
RECORD EVENTS 113
Recording FX 150
Record Mode 117
RECORD SAFE 117
Record/Edit Select Keys 10
REDO 33
RELEASE 92, 93
RESAMPLE (DSP) 82
Restoring Projects 160
RETURN TIME 114, 116
REVERB (FX) 132
REVERSE (DSP) 81
REWIND 40
ROTARY SPEAKER (FX) 141

S

SAMPLE RATE 166
Save Indicator 25
Scene, Initial 39
Scene Store/Recall 35, 121
Screen Conventions 24
SCSI 5
SCSI Disk, Record/Playback 154
SET CLOCK 178
SETUP 33, 49, 166
SHIFT 33
Shuttle Wheel 47
SIP 102

SLIP 78
SNAPSHOT RECALL 121
Soft Keys 24
SOLO 101
SOLO ISOLATE 103
SOLO LEVEL 104
SOLO Setup 101
Specifications 216
Stereo Channels 100
STEREO OUTPUTS ASSIGN 109
STOP 40
Store Locate Memory 43
Store Scene 36
Storing Mix Scenes 36
Storing FX 129
STRETCH 77
Structure 2
Studio > CR key 20
Studio Outputs 5
Sub-groups 12

T

T/C DISPLAY 50
T/C RATE 167
TALKBACK 20, 106
Talkback Level 23
TB Level 23
TEMPO 80
Tempo Maps 170
THRESHOLD 92, 93
TIMESTRETCH (DSP) 77
TIME SYNC 167
Timecode Display 23
TO 41
Transport Keys 40
TRIM FADERS 118

U

U-BANK 168, 179
UNDO/REDO 33
USB 11
USER BANK 179

V

VARISPEED (Main Screen) 50
VARI-SPEED (DSP) 80
Virtual Tracks 161

W

Waveform Generation Indicator 26
WAH (FX) 142
WHEEL 34, 47
Wordclock I/O 9

Z

Zoom in/out 53, 54